

Standard Sawtooth
Dual-Cut

#### **SERIES 3.0**

# OPERATING & INSTALLATION INSTRUCTIONS PARTS LISTS

NEW HOLLAND 890 & 892 FORAGE HARVESTERS

> HORNING MFG LLC 301 TWIN SPRINGS CT NEW HOLLAND, PA 17557

### **OPERATING INSTRUCTIONS**

- 1. Shut off all power to machine before servicing.
- 2. Grease all bearings and zerks every 8 to 10 hours (Roll bearings 1/2 to 1 pump each).
- 3. Bearings should operate under 200° F. Spit Test: If it doesn't sizzle (212°), assume normal operation.
- 4. New belts should be checked every hour for the first 5 hours of operation, daily thereafter.
- 5. Check roll clearance daily.
- 6. Roll clearance should be 1/16" as a starting point.
- 7. Increase roll gap according to moisture.
- 8. It may be necessary to lightly tap adjustment blocks downward when decreasing roll gap.
- 9. Recommended cut length for corn silage is 3/4".
- 10. Emergency stop (1/2" bolt with coupler nut between taper blocks) is factory set to keep rolls from hitting each other. See illustration **A.**
- 11. Large processor springs should be compressed to 4 7/8". (Rolls should not open under normal conditions.)
- 12. If knives, etc go through processor, measure springs. (Free length should be 5 1/4". Replace springs if less.)
- 13. Wash down unit at end of season and apply a coating of oil or grease to all unpainted surfaces, especially rolls.


#### CHANGEOVER TO HAYLAGE

- 1. Release spring loaded pins, and remove pan between auger and processor. (You may have to rotate auger to clear pan handle and latches.)
- 2. Remove belts for haylage.
- 3. Note: When putting pan back in for corn, make sure bottom end of pan is on top of step.

#### **BELT TENSION**

Tensioner spring should be compressed to 1/8" gap between spacer and washer. If your machine doesn't have a spacer, press down all belts at once. Belts should deflect 1/4" with 20 lbs. down pressure (3-belt model), and 1/4" with 25 lbs. down pressure (4-belt model). See illustration below.

For ease of belt installation adjust rolls completely together.



## **TROUBLESHOOTING**


PROBLEM	POSSIBLE CAUSE	CORRECTION
Hot Bearings	Side strain from improper installation	Loosen locking collars to release strain, then re-tighten
	Over greasing	Use only ½ to 1 pump of grease per bearing
Plugging in front of rolls	Feed pan not installed properly	Position properly
	Dried material on pan from previous season	Clean pan
	Knives too far from pan	Reset knives
	Roll teeth worn dull	Replace rolls
Processor rattles excessively when under load, from springs opening	Springs too loose or smashed From foreign material	Measure free length of springs. If less than 5 1/4", replace springs.
up	Too long cob pieces	Reduce cut length to 3/4"
	Rolls set too close for volume of crop	Adjust roll gap
Belts twisting, breaking, or getting	Misaligned sheaves	Align sheaves
hot	Belts too tight	Properly adjust belt tension
	Pan bent or out of line	Replace pan

Contact your dealer about any additional problems.

**Note:** To check pan alignment, lay flexible ruler on inside of pan when installed. Slide ruler up toward roll till it hits, then feel where ruler is hitting on roll. Should be within a 1/4" of center of rolls. Always wear gloves.

## **PARTS LISTS**

	FIGU	RE 1 PARTS LIST	
ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	S2107	NH 892 Right shield	1
2	S2106	NH 892 Top Center shield	1
3	S2105	NH 892 Left shield	1
4	S2121	NH 892 Lower back lid	1
5	CB14x12	1/4"x1/2" NC Carriage bolt zinc coated	12
6	FN14	¼" NC Serrated Flange Nut zinc	12
7	42377	Left shield spacer	2
8	FW38SAE	3/8" SAE Flat Washer	3
9	CS38x4G5	3/8"x4" NC Gr.5 Cap screw zinc plated	3
10	HC371	Rubber Hood catcher	5
11	D1039	Warning sharp rolls (orange & white)	1
12	D1060	Horning Kp 3.0 series for NH (yellow)New Style	1
13	D1004	Small gray roll adjustment Decal	1
14	D1040	Warning rotating parts (orange & white)	2
15	D1012	NH 892 Decal	1
16	D1065	Yellow Horning Krop Processor Logo	1
17	D1008	Horning Address label	1
18	D1035	2x3 Red Reflective Decal	1



**FIGURE 1 Shields** 

	FIGURE 2 PARTS LIST			
ITEM NO	PART NUMBE	RDESCRIPTION	QTY.	
1	P1364B	13.6 4-B SK Sheave	1	
2	P424BSB**	4.2 4B groove 2" Straight bore	1	
3	P604BK**	6.0 4-B SD Sheave w/SD 2" bushing and 1/2" broached keyway	1	
4	BB108K-4	BB108K Belts set of 4	1	
5	42370	NH 900 & 892 drive adapter	1	
6	42413	Heavy drive adapter washer	1	
7	CS12x4G8	1/2"x4" NC GR.8 Cap screw Z/Y	1	
8	42352	NH 892 Pan	1	
9	42358	NH 892 Return hood	1	
10	42345	NH 892 left frame assembly	1	
11	R8923.0**	Horning 892 3.0 Roll Several styles available	2	
12	42344**	NH 892 right frame assembly	1	
13	42316	892 Spacer pipe 1/2" sch. 40 Blackpipe 22 1/4" Long	2	
14	42317	892 redi-rod for spacer pipe 1/2" NC B7 rod 26"	2	
15	FN12	1/2" NC Serrated Flange Nut zinc	4	
16	N12	1/2" NC Nut (zinc coated)	4	
17	42374	892 belt tightener bracket	1	
18	LN58S	5/8"Stover (steel) Locknut (zinc coated)	1	
19	SP542	#542 zinc/yellow Die spring Idler tightener	1	
20	42320	4 Groove belt tension spacer 1.438" L	1	
21	FW58	5/8" Flat washer (zinc coated)	1	
22	N58	5/8" NC Nut (zinc coated)	3	
23	42327	5/8"x 13 1/2" NC Ready Rod W/ Nut Welded	1	
24	FB38x1G5	3/8"x1" NC Gr.5 Serrated Flange bolt zinc plated	4	
25	FN38	3/8" NC Serrated Flange Nut zinc	8	
26	CS12x1G5	1/2x1 Gade 5 zinc Capscrew	1	
27	FW12SAE	1/2" SAE Zinc Plated Flat Washer	1	
28	KEY12x12x3	1/2x1/2x3" Key	1	
29	SS38x12	3/8"-16 x 1/2" set screw	4	
30	KEY12x12x2	1/2x1/2x2" Key	1	
31	BUSK212	SK 2 1/2" Bushing	1	
32	CS516x2G8	5/16"x 2" NC Gr.8 full thread Cap Screw Z/Y	3	
33	KEY316x58x2	3/16"x5/8"x2" Key	1	
34	42306**	3.0 4-Groove Idler Arm	1	
35	CP316x112	3/16"x1 1/2" Plated cotter pin	1	
36	MW1	1" Machinery washer 14Ga.	A/R	

<sup>\*\* 2013 &</sup>amp; prior, see page 12




FIGURE 2 Processor Assembly

	F	IGURE 3 PARTS LIST	
ITEM NO	D. PART NUMBE	RDESCRIPTION	QTY.
1	CS34x15	3/4"x15" NC Gr.8 Cap screw Z/Y	1
2	CS34x14	3/4"x14" NC Gr.8 Cap screw Z/Y	1
3	SP55	Heavy 5.5" KP spring Zinc Yellow	2
4	FW34G8	3/4" Flat washer Gr.8 (Y/Z coated)	2
5	42303	Back End Bolt Support Bushing	1
6	LN34S	3/4" Stover (steel) Locknut (zinc coated)	2
7	BR2112PBHD	HD 211's 2" Eccentric Lock Wide race HD Pillow Block Bearin	2
8	42344**	NH 892 right end frame	1
9	42424	Taper Block Assembly	1
10	GH12	12" Grease hose 1/8"NPT Male both ends	1
11	GF1009	1/8" NPT straight female grease zerk	1
12	42382	Back end bolt support	1
13	42381**	Return hood catcher plate	1
14	42380**	Catcher plate spacer	1
15	42388**	NH 892 & 790 Rear slot cover	1
16	42387**	NH 892 &790 Front slot cover	1
17	FB38x12	3/8"x1/2" Gr5 serrated flange bolt zinc plated	4
18	HC371	Rubber Hood catcher	1
19	MS10-24x112	10-24 x 1 1/2" Pan Head Machinery Screw	1
20	LN10-24N	#10-24 Nylon Lock nut	1
21	FB38x1G5	3/8"x1" NC Gr.5 Serrated Flange bolt zinc plated	2
22	CB38x1	3/8"x1" NC Carriage bolt zinc coated	2
23	FN38	3/8" NC Serrated Flange Nut zinc	2
24	D1045	Belt part # BB108k-4 decal	1
25	D1064	Custom serial # plate (Aluminum)	1
26	D1018	Belt Routing decal	1
27	M4538	211's Heavy Duty Pillowblock bearing casting	2
28	BR2112	SKF 211's 2" Eccentric Lock Wide race Bearing insert	2
29	TB58x3NFG8	5/8"x3"NF Gr.8 Tapping bolt	1
30	42423	Adjustment Lockplate	1
31	SP250	Lock plate Spring	1
32	62055	Taper Block Assembly	1

<sup>\*\* 2013 &</sup>amp; prior, see page 12





FIGURE 3 Right End Frame

Note: All parts on left end frame are also in this view.

FIGURE 4 PARTS LIST			
ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	42418	892 Bot. R. front Shield bracket	1
2	42419	892 R. rear shield bracket	1
3	42420	Upper Front R. 892 Bracket	1
4	42421	890 Belt tightener spacer	2

FIGURE 5 PARTS LIST			
ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	M4622**	Cast Iron idler arm	1
2	62117	Idler Pin	1
3	CP316x112	3/16"x1 1/2" Plated cotter pin	2
4	MW1	1" Machinery washer 14Ga.	4
5	GF1012	1/8" NPT 45 deg. male zerk	1
6	GF1011	1/8" NPT Straight male grease zerk	1
7	P464BIP	4.6" 4-Groove Idler Pulley w/ Bearings	1
8	BR6304	6304 Idler bearing	2
9	M4694	4.6" 4-Groove Idler Pulley	1
10	M4517	SD Idler spacer	1
11	CS20x80MM10.9	20x80mm 10.9 zinc 2.5pitch bolt	1

<sup>\*\* 2013 &</sup>amp; prior, see page 12



**FIGURE 4 Other Parts** 




FIGURE 5 42306 Idler Arm

#### \*\*2013 & PRIOR PARTS LIST CURRENT PART PAGE/ ITEM NO. PART NO. NO. DESCRIPTION QTY. P644BK\*\* 6.4" 4-B SD sheave w/2" bushing and keyway 6/1P424BSB 1 P504BK\*\* 5.0" 4-B SD sheave w/2" bushing and keyway 6/2 P604BK 1 R8923.0 R892HT4\*\*Horning 892 Roll (2013 & prior) 6/32 Available as single part. See line 10 1 6/442306 N/A Call Non-stock. Must custom order 8/5 42344 1 2 8/6 42381 HM1240\*\* Horseshoe catcher 42380 N/A Not used on 2013 & prior 8 / 70 0 8/8 42388 N/A Not used on 2013 & prior Not used on 2013 & prior 8/9 42387 N/A 0 Kp idler arm 2013 & prior 10 / 10 M4622 42435\*\* 1